

## SECTION 10

# CHARGING SYSTEM

### NOTE:

For the items not found in this section, refer to the same section of '88 MODEL SERVICE MANUAL.

## CONTENTS

<b>10-1. ALTERNATOR</b> .....	<b>10-1</b>
GENERAL DESCRIPTION .....	10-1
DATA AND SPECIFICATION .....	10-2

10

### 10-1. ALTERNATOR

#### GENERAL DESCRIPTION

The maximum output of this alternator is 50A. Its structure and operation are the same as the one used for the '88 model vehicle. The component parts also remain the same except the rotor.




Fig. 10-1




Fig. 10-2

#### DATA AND SPECIFICATION

Nominal operating voltage	12 volts
Max. alternator output	50A
Polarity	Negative ground
No-load alternator speed	1,110 rpm (r/min)
Regulated voltage	14.5 ± 0.3V
Direction of rotation	Clockwise as viewed from pulley side
Maximum permissible alternator speed	15,000 rpm (r/min)
Working temperature range	-30 ~ 90°C (-22 ~ 194°F)
Rectification	Full wave rectification

The graph given below shows the alternator frame temperature to output voltage relationship. Use it as reference when checking output of the alternator.




Fig. 10-3

## SECTION 11

# CLUTCH

### NOTE:

For the items not found in this section, refer to the same section of '88 MODEL SERVICE MANUAL.

## CONTENTS

### 11-5. MAINTENANCE SERVICES ..... 11-1

11

### 11-5. MAINTENANCE SERVICES

#### NOTE:


For the maintenance service procedure not found in this section, refer to the same section of '88 MODEL SERVICE MANUAL.

#### Clutch Pedal Height

Check to make sure that clutch pedal height is within "A" range as illustrated.

Clutch pedal height "A"	148 – 154 mm (5.83 – 6.06 in.)
-------------------------	-----------------------------------

If clutch pedal height is out of above specification, adjust it by turning pedal stopper bolt. Be sure to tighten lock nut after adjustment.



**SECTION 15**

**PROPELLER SHAFTS**

**NOTE:**  
For the items not found in this section, refer to the same section of '88 MODEL SERVICE MANUAL.


**CONTENTS**

**15-5. TIGHTENING TORQUE..... 15-1**

**15-5. TIGHTENING TORQUE**

**Bolts & Nuts**  
Check following bolts and nuts for tightness and retighten them as necessary:

Tightening torque for propeller shaft (Universal joint flange) bolts and nuts	N·m	kg·m	lb·ft
	50 – 60	5.0 – 6.0	36.5 – 43.0



## SECTION 19

# BRAKES

### NOTE:

For the items not found in this section, refer to the same section of '88 MODEL SERVICE MANUAL.

### CONTENTS

19-1. GENERAL DESCRIPTION .....	19-2
19-4. MASTER CYLINDER .....	19-9
19-5. BRAKE BOOSTER .....	19-12
19-7. BRAKE PIPES AND HOSES .....	19-24
19-10. SPECIAL TOOLS .....	19-26

### NOTE:

All brake fasteners are important attaching parts in that they could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of all parts. There is to be no welding as it may result in extensive damage and weakening of the metal.

### WARNING:

When servicing wheel brake parts, do not create dust by grinding, sanding brake linings, or by cleaning wheel brake parts with a dry brush or with compressed air. Many wheel brake parts contain asbestos fibers which can become airborne if dust is created during servicing. Breathing dust containing asbestos fibers may cause serious bodily harm. A water dampened cloth or water based solution should be used to remove any dust on brake parts. Equipment is commercially available to perform this washing function. These wet methods will prevent asbestos fibers from becoming airborne.

## 19-1. GENERAL DESCRIPTION

When the foot brake pedal is depressed, hydraulic pressure is developed in the master cylinder to actuate pistons (two in front and four in rear).

The master cylinder is a tandem master cylinder. Two brake pipes are connected to the master cylinder and they make two independent circuits. One connects the front brakes (right & left) and the other connects the rear brakes (right & left).

The proportioning and bypass valve (P & B valve) is included within the brake circuit which connects the master cylinder and the rear wheel brake.

In this brake system, the disc brake type is used for the front wheel brake and a drum brake type (leading/trailing shoes) for the rear wheel brake.

The parking brake system is mechanical. It applies brake force to only rear wheels by means of the cable and mechanical linkage system. The same brake shoes are used for both parking and foot brakes.




Fig. 19-1

## MASTER CYLINDER




Fig. 19-2

## MASTER CYLINDER ASSEMBLY

### [GENERAL DESCRIPTION]

The master cylinder has two pistons and three piston cups. Its hydraulic pressure is produced in the primary ("a" in the below figure) and secondary ("b") chambers. The hydraulic pressure produced in the primary chamber ("a") acts on the rear wheel brakes (right & left).

Also, the hydraulic pressure produced in the secondary chamber ("b") acts on the front wheel brakes (right & left).

### NOTE:

Replace all components included in repair kits to service this master cylinder. Lubricate rubber parts with clean, fresh brake fluid to ease assembly. Do not use lubricated shop air on brake parts as damage to rubber components may result. If any hydraulic component is removed or brake line disconnected, bleed the brake system. The torque values specified are for dry, unlubricated fasteners.




Fig. 19-3

### [Master cylinder OPERATION]

#### Normal operation

Depressing the brake pedal forces the primary piston "A" to move to the left in the below figure and consequently the hydraulic pressure is produced in the chamber "a".

By means of this pressure and the return spring force, the secondary piston "B" is also pushed to the left and thus the hydraulic pressure is produced in the chamber "b".




Fig. 19-3-1



#### One-circuit operation (Primary chamber "a" circuit failure)

Depressing the brake pedal forces the primary piston "A" to move as described previously, but since the brake circuit connected to the chamber "a" cannot hold the pressure, no pressure is produced in the fluid immediately ahead of the piston "A". The piston "A" keeps moving while compressing the spring and when it reaches the retainer, the piston "B" is pushed and begins to move. This causes the pressure to rise in the chamber "b" and the pressure acts on front wheel brakes (right & left).




Fig. 19-4

#### One-circuit operation (Secondary chamber "b" circuit failure)

In this case, the leftward movement of the piston "A" has but little effect in causing the fluid pressure to rise in the chamber "a" in the beginning, because the initial rise of the fluid pressure causes the piston "B" to promptly yield and move to the left. However, when the forward end of the piston "B" comes to the head of the cylinder and stops there, the leftward movement of the piston "A" becomes effective. Thus the fluid pressure is produced in the chamber "a" and it acts on rear wheel brakes (right & left). The below figure shows secondary piston "B" at halt.




Fig. 19-4-1

## BOOSTER ASSEMBLY

### [GENERAL DESCRIPTION]

The booster is located between the master cylinder and the brake pedal. It is so designed that the force created when the brake pedal is depressed is mechanically increased combined with the engine vacuum. The booster has a diaphragm of  $\phi$  180 mm effective diameter. Its operation is described in the following pages.

### NOTE:

- Use all components included in repair kits to service this booster. Lubricate rubber parts, where indicated, with silicone grease provided in kits. The torque values specified are for dry, unlubricated fasteners. If any hydraulic component is removed or brake line disconnected, bleed the brake system.
- Never lubricate any hydraulic component with silicone grease.




Fig. 19-12

## [Booster OPERATION]




Fig. 19-13-1 Vacuum Booster Assembly

When the brake pedal is depressed, the force is transmitted to the piston of the master cylinder through the valve operating rod, booster air valve, reaction disc and piston rod. At the same time, the force of the booster piston developed due to the pressure difference between the two chambers "A" and "B" in the above figure is added to it.

The end of the booster control valve has a double function of a vacuum valve and air valve. That is, as shown in the figure, the booster control valve closes between the "A" and "B" chambers as its outer end "C" contacts the booster piston seat and opens as "C" leaves the booster piston seat (vacuum valve function). Also it closes between the "B" chamber and outside air as its inner end "D" contacts the air valve seat and opens as "D" leaves the air valve seat (air valve function).

### When foot brake pedal is not depressed

The valve operating rod is pushed to the right by the spring force as shown. The air valve is also enough to the right to contact the valve stopper key as shown. In this state, the vacuum valve (control valve "C") is open and the air valve (control valve "D") is closed. Thus the chambers "A" and "B" conduct and share the same negative pressure (because of no pressure difference) which allows the return spring to push the booster piston to the right.




Fig. 19-13-2 Vacuum Booster Assembly

#### When foot brake pedal is depressed

Being pushed by the operating rod, the booster air valve moves to the left as shown. Then the control valve is pushed against the booster piston seat closely by the valve spring force. Thus the vacuum valve (control valve "C") is closed to cut off between the chambers "A" and "B". At this time the air valve (control valve "D") is still closed.




Fig. 19-14-1

As the booster air valve moves further to the left, it leaves the control valve and the air valve (control valve "D") opens to allow the air to flow into the chamber "B". The entry of air causes a difference in pressures between the chambers "A" and "B". When this pressure difference grows greater than the piston return spring force, the booster piston moves to the left and the booster control valve also moves to the left. The resulting air valve (control valve "D") closure stops the air flow into the chamber "B" and its pressure remains as it is. In this way, a small brake pedal depressing force is made into a strong push to the master cylinder push rod to produce high hydraulic pressure.




Fig. 19-14-2

#### When foot brake pedal is released

When the brake pedal is released, the booster air valve returns to the right by the master cylinder piston return force and the air valve return spring force as shown. Then the vacuum valve (control valve "C") opens and causes negative pressure in the chamber "B". The result is that the master cylinder piston and booster piston return to their original positions. This is the same state as described under "When foot brake pedal is not depressed".




Fig. 19-14-3

#### Reference

Should any of the vacuum related parts in the booster be faulty, the brake force is not increased. Even then, however, the brake depressing force is transmitted to the valve operating rod, booster air valve, valve stopper key and booster piston in that order, to push the master cylinder push rod. Thus, the braking operation itself will not fail.




Fig. 19-14-4

## 19-4. MASTER CYLINDER

### REMOVAL

- 1) Remove air cleaner case. (For right hand steering vehicle)
- 2) Disconnect reservoir lead wire at coupler.
- 3) Clean outside of reservoir.
- 4) Take out fluid with syringe or such.
- 5) Remove reservoir connector pin by using special tool.




Fig. 19-56

- 6) Remove reservoir.
- 7) Disconnect two brake pipes from master cylinder.

### NOTE:

Do not allow brake fluid to get on painted surfaces.

- 8) Remove master cylinder mounting nuts.
- 9) Remove master cylinder.




Fig. 19-56-1

### DISASSEMBLY

- 1) Remove circlip.
- 2) Remove primary piston.




Fig. 19-57

- 3) Remove piston stopper bolt. Then remove secondary piston by blowing compressed air into hole from which piston stopper bolt was removed.  
Be cautious during removal as secondary piston jumps out.




Fig. 19-58

## INSPECTION OF COMPONENTS

### Master Cylinder Inner Parts

Inspect all disassembled parts for wear or damage, and replace parts if necessary.

#### NOTE:

- Wash disassembled parts with brake fluid.
- Do not reuse piston cups.




Fig. 19-59

Inspect master cylinder bore for scoring or corrosion. It is best to replace a corroded cylinder. Corrosion can be identified as pits or excessive roughness.

#### NOTE:

Polishing bore of master cylinder with cast aluminum body with anything abrasive is prohibited, as damage to cylinder bore may occur.

Rinse cylinder in clean brake fluid. Shake excess rinsing fluid from cylinder. Do not use a cloth to dry cylinder, as lint from cloth will remain on cylinder bore surface.

## Reservoir

#### NOTE:

Do not use shock absorber fluid or any other fluid which contains mineral oil. Do not use a container which has been used for mineral oil or a container which is wet from water. Mineral oil will cause swelling and distortion of rubber parts in the hydraulic brake system and water will mix with brake fluid, lowering the fluid boiling point. Keep all fluid containers capped to prevent contamination.

Fluid to fill reservoir with is indicated on reservoir cap of the vehicle with embossed letters or in owner's manual supplied with the vehicle. Add fluid up to MAX line.





Fig. 19-60

## ASSEMBLY

### NOTE:

Before assembling, wash each part in fluid recommended to use for that vehicle.

- 1) Assemble secondary piston as shown below.
- 2) Install secondary piston assembly into cylinder.



- |                                  |                                    |
|----------------------------------|------------------------------------|
| 1. Piston stopper circlip        | 7. Piston cup                      |
| 2. Piston stopper                | 8. Secondary piston                |
| 3. Cylinder cup and plate        | 9. Return spring secondary seat    |
| 4. Primary piston                | 10. Secondary piston return spring |
| 5. Piston cup                    | 11. Secondary piston stopper bolt  |
| 6. Secondary piston pressure cup | 12. Master cylinder body           |
|                                  | 13. Sealing                        |

Fig. 19-61

- 3) Install primary piston in cylinder.
- 4) Depress, and install circlip.




Fig. 19-62

- 5) Install piston stopper bolt with pistons pushed in all the way and tighten it to specified torque.
- 6) For installation on vehicle, refer to INSTALLATION.

## PRECAUTION OF INSTALLATION


### NOTE:

Adjust clearance between booster piston rod and primary piston with special tool (See page 19-20).

- 1) Install master cylinder as shown and torque attaching nuts to specification.
- 2) Connect 2 hydraulic lines and torque flare nuts to specification.
- 3) When using new grommets, lubricate them with the same fluid as the one to fill reservoir with. Then press-fit grommets to master cylinder. Grommets must be seated in place.
- 4) Install reservoir and drive in reservoir pin.

### NOTE:

Drive in reservoir pin till both of its ends at the right and left of reservoir become the same length.



1. Reservoir
2. Pin

Fig. 19-63

- 5) Connect reservoir lead wire.
- 6) Fill reservoir with specified fluid.
- 7) Upon completion of installation, check for fluid leakage.




Fig. 19-64

## 19-5. BRAKE BOOSTER

### REMOVAL

- 1) Remove master cylinder assembly, referring to steps 1) – 4) and 7) – 9) of its REMOVAL on page 19-9.
- 2) Disconnect vacuum hose from booster.
- 3) Disconnect push rod clevis from brake pedal arm.
- 4) Remove attaching nuts and then booster as shown.

### INSTALLATION

#### NOTE:

- Adjust clearance between booster piston rod and master cylinder piston with special tool. (See page 19-20.)
  - Check length of push rod clevis. (See page 19-19.)
- 1) Install booster to dash panel as shown. Then connect booster push rod clevis to pedal arm with clevis pin and split pin.
  - 2) Torque booster attaching nuts to specification.
  - 3) Install master cylinder to booster and torque master cylinder mounting nuts to specification.
  - 4) Connect two brake pipes and torque flare nuts to specification.
  - 5) Connect booster vacuum hose.
  - 6) Connect reservoir lead wire at coupler.
  - 7) Install air cleaner case.
  - 8) Fill reservoir with specified fluid.
  - 9) Bleed air from brake system.
  - 10) After installing, check pedal height and play.
  - 11) Perform brake test and check each installed part for fluid leakage.




Fig. 19-65



## DISASSEMBLY




Fig. 19-66

1) Remove push rod clevis and nut.




Fig. 19-67

2) Attach booster to special tool (A) as shown and install special tool (B) to booster as shown.

### NOTE:

- When attaching, check to be sure that booster vacuum pipe is not in faulty contact with base of special tool (A).
- Be careful not to over-tighten nuts, or booster body will be deformed.




Fig. 19-68

- 3) Turn special tool bolt clockwise until No. 1 body projecting part and No. 2 body depressed part fit each other.

Once they are matched, make match marking on No. 1 and No. 2 bodies to facilitate their installation.




Fig. 19-69

- 4) Detach booster from special tool and separate No. 1 body and No. 2 body. Remove piston return spring.

**WARNING:**

When separating two bodies, carefully hold both bodies to prevent either body from jumping off by spring force.

- 5) From booster No. 2 body, remove piston rod, boot, air cleaner element and air cleaner separator in this order.




Fig. 19-70

- 6) Remove valve stopper key cushion from stopper key.




Fig. 19-71

- 7) While compressing air valve spring (by moving rod up and down as shown), remove valve stopper key. Then remove booster air valve assembly from booster piston.

**NOTE:**

Booster air valve assembly can't be disassembled.




Fig. 19-72

8) Remove diaphragm circular ring from booster piston.




Fig. 19-72-1

9) Remove diaphragm from booster piston.

**NOTE:**

Don't use driver or other tool for removal. Pull it off by hand carefully handling piston groove area where diaphragm is fitted.




Fig. 19-73

10) Remove reaction disc from booster piston rod.




Fig. 19-74

11) Remove oil seal from booster No. 2 body with special tools as shown.

**NOTE:**

Removed oil seal must not be reused.




Fig. 19-75

## ASSEMBLY

### NOTE:

Be sure to use silicon grease wherever application of grease is instructed during assembly.

- 1) Apply grease to new oil seal outer surface and oil seal lip as shown.  
Press-fit new oil seal to booster No. 2 body by using special tools (C) and (D).




Fig. 19-76

- 2) Install retainer to diaphragm.




Fig. 19-77

- 3) Install diaphragm to booster piston by hand.




Fig. 19-78

- 4) Install new diaphragm circular ring, referring to figure below for its proper installing direction.

### NOTE:

Be careful not to cause damage to piston when installing.




Fig. 19-79

- 5) Install booster air valve assembly to booster piston. Before installation, apply grease as shown.




Fig. 19-80

- 6) Compress air valve assembly and insert valve stopper key.

**NOTE:**

**Don't compress air valve assembly forcibly.**




Fig. 19-81

- 7) Install valve stopper key cushions.

**NOTE:**

**Make sure that it is installed in proper direction and cushion is fitted to notch in key.**




Fig. 19-82

- 8) Install booster piston to booster No. 2 body.




Fig. 19-83

- 9) Install air cleaner separator and then element to rod of air valve assembly.

- 10) Install body boot to booster No. 2 body. Both ends of boot must be fitted securely as shown.




Fig. 19-84

- 11) Install reaction disc to booster piston rod after greasing its outer face.

**NOTE:**

Make sure that no air exists between piston rod and reaction disc.




Fig. 19-85

- 12) Place No. 1 body on special tool (A).




Fig. 19-86

- 13) Install piston rod, rod retainer and piston return spring to booster piston as shown below. Then install them to booster No. 1 body.




Fig. 19-87

- 14) Put No. 1 and No. 2 bodies together by aligning markings made before disassembly. Holding No. 2 body with upper plate (special tool) as shown, torque two nuts equally to specification.

Special tool nuts tightening torque	N·m	kg·m	lb·ft
	3 - 5	0.3 - 0.5	2.2 - 3.6

**NOTE:**

When holding No. 2 body, use care so that diaphragm is not caught by projections at 16 locations around No. 1 body.




Fig. 19-88

- 15) Turn special tool bolt counterclockwise until No. 1 body projecting part comes to mid-position of No. 2 body depressed parts as shown.




Fig. 19-89

- 16) Install push rod clevis so that below measurement "A" is obtained and torque nut to specification.




Fig. 19-90

- 17) Remove booster from special tool.

**NOTE:**

Whenever booster was disassembled, make sure to check clearance between piston rod and master cylinder piston after reassembly. (For details, refer to page 19-20.)

- 18) For installation of booster, see steps 1) to 11) of its INSTALLATION on page 19-12.

## INSPECTION

### 1. INSPECT BOOSTER INNER PARTS

#### NOTE:

After disassembly, soak all metal parts in ethyl alcohol. Wipe rubber diaphragm and plastic parts with a clean cloth. Use ethyl alcohol damped cloth to wipe out heavy dirt. Application of much ethyl alcohol especially to rubber parts is prohibited.

#### RUBBER PARTS

Wipe fluid from rubber parts and carefully inspect each rubber part for cuts, nicks or other damage. These parts are key to air flow control. If there is any question as to serviceability of rubber parts, **REPLACE** them.

#### METAL PARTS

**BADLY DAMAGED ITEMS, OR THOSE WHICH WOULD TAKE EXTENSIVE WORK OR TIME TO REPAIR, SHOULD BE REPLACED. IN CASE OF DOUBT, INSTALL NEW PARTS.**

### 2. INSPECT/ADJUST CLEARANCE BETWEEN BOOSTER PISTON ROD AND MASTER CYLINDER PISTON

The length of booster piston rod is adjusted to provide specified clearance between piston rod end and master cylinder piston.




Fig. 19-91

- Before measuring clearance, push piston rod several times so as to make sure reaction disc is in place.

- Take measurement with gasket installed to master cylinder.
- Keep inside of booster at atmospheric pressure for measurement.

- 1) Set special tool (E) on master cylinder and push pin until contacts piston.




Fig. 19-92

- 2) Turn special tool upside down and place it on booster. Adjust booster piston rod length until rod end contacts pin head.
- 3) Adjust clearance by turning adjusting screw of piston rod.




Fig. 19-93






Fig. 19-94

#### Reference

When adjusted as above, if negative pressure is applied to booster with engine at idle, piston to piston rod clearance should become 0.25 – 0.5 mm (0.010 – 0.020 in.).

### 3. INSPECT BOOSTER OPERATION

There are two ways to perform this inspection, with and without a tester. Ordinarily, it is possible to roughly determine its condition without using a tester.

#### NOTE:

For this check, make sure that no air is in hydraulic line.

#### INSPECTION WITHOUT TESTER

##### Check Air Tightness

- 1) Start engine.
- 2) Stop engine after running for 1 to 2 minutes.
- 3) Depress brake pedal several times with the same load as in ordinary braking and observe pedal travel. If pedal goes down deep the first time but its travel decreases as it is depressed the second and more times, air tightness is obtained.




Fig. 19-95

- 4) If pedal travel doesn't change, air tightness isn't obtained.




Fig. 19-96

#### NOTE:

If defective, inspect vacuum lines and sealing parts, and replace any faulty part. When this has been done, repeat the entire test!

### Check Operation

- 1) With engine stopped, depress brake pedal several times with the same load and make sure that pedal travel doesn't change.




Fig. 19-97

### Check Air Tightness Under Load

- 1) With engine running, depress brake pedal. Then stop engine while holding brake pedal depressed.




Fig. 19-99

- 2) Start engine while depressing brake pedal. If pedal travel increases a little, operation is satisfactory. But no change in pedal travel indicates malfunction.




Fig. 19-98

- 2) Hold brake pedal depressed for 30 seconds. If pedal height does not change, condition is good. But it isn't if pedal rises.




Fig. 19-100

#### 4. BOOSTER INSPECTION TABLE

Part	Inspect For	Corrective Action
1. Booster piston	Cracks, distortion or damage.	Replace.
2. Air valve ass'y (Control valve and spring)	Damaged or worn seal surfaces.	Replace.
3. Reaction disc	Damage or wear.	Replace.
4. Diaphragm, boot and rubber	Damage.	Replace.
5. Piston rod	Damage or bend.	Replace.
6. Booster No. 1 & No. 2 body	1. Scratches, scores, pits, dents, or other damage affecting rolling or sealing of diaphragm or other seals. 2. Cracks, damage at ears, damaged threads on studs. 3. Bent or nicked locking lugs. 4. Loose studs.	Replace, unless easily repaired.  Replace, unless easily repaired.  Replace, unless easily repaired.  Replace.
7. Air filters and separator	Dirt.	Replace.







Fig. 19-101









## 19-7. BRAKE PIPES AND HOSES

### NOTE:

For the service informations not found in this section, refer to the same section of '88 MODEL SERVICE MANUAL.

### REMOVAL AND INSTALLATION















## 19-10. SPECIAL TOOLS

Shown below are special tools necessary when servicing brake system of '90 MODEL. The same ones are currently used for other models.

\* : marked ones are used for SAMURAI '88 MODEL.

\*\* : marked ones are used for SIDEKICK.

 <p>* 09950-88210 Booster overhaul tool set</p>	 <p>* 09950-78210 Flare nut wrench (10 mm)</p>	 <p>** 09950-96010 Booster piston rod gauge</p>	 <p>** No. 1 09951-16020</p>  <p>* No. 2 09951-18210</p> <p>Booster No. 2 body Oil seal remover &amp; Installer No. 1, No. 2</p>
 <p>** 09951-16010 Booster overhaul attachment</p>	 <p>** 09952-16010 Booster piston rod adjuster</p>	 <p>** 09922-85811 Connector pin remover</p>	 <p>* 09943-35511 Brake drum remover (Front wheel hub remover)</p>
 <p>* 09942-15510 Sliding hammer</p>			

## **SECTION 21**

# **BODY ELECTRICAL EQUIPMENT**

**NOTE:**

For the items not found in this section, refer to the same section of '88 MODEL SERVICE MANUAL.

### **CONTENTS**

<b>21- 1. COMBINATION METER .....</b>	<b>21-2</b>
<b>21-16. WIRING DIAGRAM. .</b>	<b>Wiring diagrams are attached at the end of this manual.</b>
<b>21-17. DAYTIME RUNNING LIGHT SYSTEM .....</b>	<b>21-3</b>



## 21-1. COMBINATION METER

### COMBINATION METER CIRCUIT

The '90 model combination meter includes a vehicle speed sensor (VSS) in addition to the same components as the '88 model combination meter.

#### NOTE:

Whether equipped with \*marked parts or not depends on vehicle specifications.




Fig. 21-1 Combination Meter Wiring



## 21-17. DAYTIME RUNNING LIGHT (D.R.L.) SYSTEM (If equipped)

### GENERAL DESCRIPTION

If equipped with this system, the headlights light, though dimmer than the low beam, when the following three conditions are all met. Also, D.R.L. indicator light in the combination meter comes ON at the same time.

Conditions for D.R.L. system operation

1. The engine is running.
2. The parking brake is not applied.
3. The lighting switch is at either "OFF" or "clearance light" position.




Fig. 21-2 D.R.L. System Circuit

### NOTE:

- D.R.L. controller is located at the backside of glove box.




Fig. 21-3

- D.R.L. resistor is located inside front fender LH panel at fender apron panel.





Fig. 21-4

## TROUBLE DIAGNOSIS

When a trouble has occurred in this system, check it by using the following flow chart 1) or trouble-diagnosis chart 2) depending on symptom.

### 1) D.R.L. system does not operate.



2) D.R.L. system fails to stop.

Trouble	Possible cause	Correction
D.R.L. system remains operating even after engine stop.	D.R.L. controller faulty. W/R circuit faulty.	Replace controller. Repair.
D.R.L. system remains operating even after parking brake applied.	Parking brake switch faulty. V/G circuit faulty.	Replace switch. Repair.
D.R.L. system remains operating even after lighting switch turned ON.	Lighting switch faulty. Br/Y circuit or its ground faulty.	Repair or replace switch. Repair.

# SECTION 22

## SERVICE DATA

### CONTENTS

<b>22-1. SPECIFICATIONS .....</b>	<b>22-1</b>
<b>22-2. SERVICE DATA .....</b>	<b>22-4</b>

### 22-1. SPECIFICATIONS

Item	Models	Convertible/Hard Top
ENGINE		
Type	Four-stroke cycle, water cooled, OHC	
Number of cylinders	4	
Lubrication system	Wet sump	
Bore	74.0 mm (2.91 in.)	
Stroke	75.5 mm (2.97 in.)	
Piston displacement	1,298 cm <sup>3</sup> (1,298 cc, 79.2 cu. in.)	
Compression ratio	9.5 : 1	
Electronic Fuel Injection system	Single-point throttle body fuel injection system	
Air cleaner	Polyester fiber element (Dry type)	
ELECTRICAL		
Ignition timing	8° B.T.D.C. at 800 r/min (rpm)	
Standard spark plug	NGK BPR5ES or NIPPON DENSO W20EPR-U	
Starter	Magnetic shift type	
Generator	Alternator	
Battery	12V, 137 kC (38 Ah)/5HR	
Headlight	12V, 60/50W	
Turn signal light	12V, 32 cp	
Clearance light	12V, 4 cp	

Item \ Models		Convertible/Hard Top
Tail/Brake light		12V, 3/32 cp
Side marker light		12V, 3.8W
License plate light		12V, 4 cp
Back-up light		12V 32 cp
Interior light		12V, 5W
Meter pilot light		12V, 1.4W
Main fuse		0.5 mm <sup>2</sup> (fusible link)
Fuse box		10/10/15/15/15/20/15/15/10/15/15/20A
<b>POWER TRANSMISSION</b>		
Clutch type		Dry, single disc
Transmission type		5-forward all synchromesh, 1 reverse
Final reduction ratio (Differential)		3.727
Transmission gear ratios	low	3.852
	2nd	1.947
	3rd	1.423
	4th	1.000
	5th	0.864
	reverse	3.466
Transfer gear ratios	low range	2.268
	high range	1.409
Overall reduction ratios:		
Low range	low	30.869
	2nd	16.457
	3rd	12.028
	4th	8.452
	5th	7.303
	reverse	29.297
High range	low	19.177
	2nd	10.224
	3rd	7.472
	4th	5.251
	5th	4.537
	reverse	18.201

Item		Models	Convertible/Hard Top
WHEEL AND SUSPENSION			
Tire size: front and rear		P205/70 R15	
Tire pressure	front	140 kPa (1.40 kg/cm <sup>2</sup> , 20 psi)	
	rear	140 kPa (1.40 kg/cm <sup>2</sup> , 20 psi)-unladen	
		180 kPa (1.80 kg/cm <sup>2</sup> , 26 psi)-laden	
Suspension type	front	Leaf spring	
	rear	Leaf spring	
STEERING			
Turning radius		5.1 m (16.7 ft)	
Steering gear box		Ball nut type	
Toe-in		2 – 6 mm (0.08 – 0.24 in.)	
Camber angle		1° 00'	
Caster angle		3° 30'	
King pin angle		9° 00'	
BRAKE SYSTEM			
Type		4-wheel, hydraulic	
Wheel brake	front	Disc brake (floating caliper type)	
	rear	Drum brake (leading and trailing)	
Parking brake		Mechanical actuated on rear wheels	
CAPACITIES			
Cooling solution		4.8 ℓ (10.1/8.4 US/Imp pt)	
Fuel tank		40ℓ (10.6/8.8 US/Imp gal)	
Engine oil		3.5 ℓ (7.4/6.2 US/Imp pt)	
Transmission oil		1.3 ℓ (2.7/2.3 US/Imp pt)	
Differential gear box oil	front	2.0 ℓ (4.2/3.5 US/Imp pt)	
	rear	1.5 ℓ (3.2/2.6 US/Imp pt)	
Transfer gear box oil		0.8 ℓ (1.7/1.4 US/Imp pt)	

## 22-2. SERVICE DATA

### ENGINE

Item			Standard	Service Limit
Compression pressure			14.0 kg/cm <sup>2</sup> (199.0 psi)	12.0 kg/cm <sup>2</sup> (170.0 psi)
	Difference between cylinders		_____	1.0 kg/cm <sup>2</sup> (14.2 psi)
Valve lash (clearance)	Cold (When coolant temperature is 15 ~ 25°C or 59 ~ 77°F)	Inlet	0.13 ~ 0.18 mm (0.0051 ~ 0.0071 in.)	_____
		Exhaust	0.15 ~ 0.21 mm (0.0059 ~ 0.0083 in.)	_____
	Hot (When coolant temperature is 60 ~ 68°C or 140 ~ 154°F)	Inlet	0.23 ~ 0.27 mm (0.009 ~ 0.011 in.)	_____
		Exhaust	0.26 ~ 0.30 mm (0.0102 ~ 0.0118 in.)	_____
Cylinder head	Flatness of gasketed surface		_____	0.05 mm (0.002 in.)
	Flatness of manifold seat	Inlet	_____	0.1 mm (0.004 in.)
		Exhaust	_____	0.1 mm (0.004 in.)
	Valve seat	Inlet	1.3 ~ 1.5 mm (0.0512 ~ 0.0590 in.)	_____
		Exhaust	1.3 ~ 1.5 mm (0.0512 ~ 0.0590 in.)	_____
	Seating angle		45°	_____
Valve, valve spring & cam shaft	Valve guide hole diameter (In & Ex) (over size)		12.030 ~ 12.048 mm (0.4736 ~ 0.4743 in.)	_____
	Camshaft/Journal clearance		0.050 ~ 0.091 mm (0.0020 ~ 0.0036 in.)	0.15 mm (0.0059 in.)
	Camshaft thrust clearance		_____	0.75 mm (0.0295 in.)
	Cam height (Base circle + lift)	Inlet	38.136 mm (1.5014 in.)	38.036 mm (1.4975 in.)
		Exhaust	38.136 mm (1.5014 in.)	38.036 mm (1.4975 in.)
	Camshaft runout		_____	0.10 mm (0.0039 in.)
	Valve stem diameter	Inlet	6.965 ~ 6.980 mm (0.2742 ~ 0.2748 in.)	_____
		Exhaust	6.950 ~ 6.965 mm (0.2737 ~ 0.2742 in.)	_____
	Valve guide I.D.	Inlet	7.000 ~ 7.015 mm (0.2756 ~ 0.2761 in.)	_____
		Exhaust	7.000 ~ 7.015 mm (0.2756 ~ 0.2761 in.)	_____
	Valve guide-to-valve stem clearance	Inlet	0.020 ~ 0.050 mm (0.0008 ~ 0.0019 in.)	0.07 mm (0.0027 in.)
		Exhaust	0.035 ~ 0.065 mm (0.0014 ~ 0.0025 in.)	0.09 mm (0.0035 in.)
	Thickness of valve head periphery	Inlet	1.0 mm (0.039 in.)	0.6 mm (0.0236 in.)
		Exhaust	1.0 mm (0.039 in.)	0.7 mm (0.0275 in.)
	Contact width of valve and valve seat	Inlet	1.3 ~ 1.5 mm (0.0512 ~ 0.0590 in.)	_____
		Exhaust	1.3 ~ 1.5 mm (0.0512 ~ 0.0590 in.)	_____
	Valve spring free length	Inlet	49.3 mm (1.9409 in.)	48.1 mm (1.8937 in.)
		Exhaust	49.3 mm (1.9409 in.)	48.1 mm (1.8937 in.)
	Valve spring preload	Inlet	24.8 ~ 29.2 kg (54.7 ~ 64.3 lb) for fitting length 41.5 mm (1.63 in.)	22.8 kg (50.2 lb) for fitting length 41.5 mm (1.63 in.)
		Exhaust	24.8 ~ 29.2 kg (54.7 ~ 64.3 lb) for fitting length 41.5 mm (1.63 in.)	22.8 kg (50.2 lb) for fitting length 41.5 mm (1.63 in.)

Item			Standard	Service Limit	
Valve, valve spring & cam shaft	Valve stem end deflection	Inlet	_____	0.14 mm	(0.005 in.)
		Exhaust	_____	0.18 mm	(0.007 in.)
	Stock allowance of valve stem end face		_____	0.5 mm	(0.019 in.)
	Valve head radial runout		_____	0.08 mm	(0.003 in.)
	Valve spring squareness		_____	2.0 mm	(0.079 in.)
	Valve guide protrusion (In. & Ex.)		14 mm (0.55 in.)	_____	_____
Rocker arm shaft and rocker arm	Rocker shaft O.D.		15.973 ~ 15.988 mm (0.628 ~ 0.629 in.)	_____	_____
	Rocker arm I.D.		16.000 ~ 16.018 mm (0.629 ~ 0.630 in.)	_____	_____
	Shaft-to-arm clearance	Inlet	0.012 ~ 0.045 mm (0.0005 ~ 0.0017 in.)	0.09 mm	(0.0035 in.)
		Exhaust	0.012 ~ 0.045 mm (0.0005 ~ 0.0017 in.)	0.09 mm	(0.0035 in.)
	Rocker shaft runout		_____	0.12 mm	(0.004 in.)
Cylinder	Flatness of gasketed surface		0.03 mm (0.0012 in.)	0.06 mm	(0.0024 in.)
	Cylinder bore (S.T.D.)		74.00 ~ 74.02 mm (2.9134 ~ 2.9142 in.)	74.15 mm	(2.9193 in.)
	Cylinder bore out-of-round and taper		_____	0.10 mm	(0.0039 in.)
	Cylinder-to-piston clearance		0.02 ~ 0.04 mm (0.0008 ~ 0.0015 in.)	_____	_____
Piston	Piston diameter	Standard	73.970 ~ 73.990 mm (2.9122 ~ 2.9129 in.)	_____	_____
		Oversize: 0.25 mm (0.0098 in.)	74.220 ~ 74.230 mm (2.9220 ~ 2.9224 in.)	_____	_____
		Over size: 0.50 mm (0.0196 in.)	74.470 ~ 74.480 mm (2.9319 ~ 2.9322 in.)	_____	_____
	Piston ring groove width	Top ring	1.22 ~ 1.24 mm (0.0480 ~ 0.0488 in.)	_____	_____
		2nd ring	1.51 ~ 1.53 mm (0.0594 ~ 0.0602 in.)	_____	_____
		Oil ring	2.81 ~ 2.83 mm (0.1106 ~ 0.1114 in.)	_____	_____
	Piston pin diameter		16.995 ~ 17.000 mm (0.6691 ~ 0.6693 in.)	_____	_____
Piston ring	Piston ring thickness	Top ring	1.17 ~ 1.19 mm (0.0461 ~ 0.0468 in.)	_____	_____
		2nd ring	1.47 ~ 1.49 mm (0.0578 ~ 0.0586 in.)	_____	_____
		Oil ring	0.45 mm (0.0177 in.)	_____	_____
	Ring clearance in groove	Top ring	0.03 ~ 0.07 mm (0.0012 ~ 0.0027 in.)	0.12 mm	(0.0047 in.)
		2nd ring	0.02 ~ 0.06 mm (0.0008 ~ 0.0023 in.)	0.10 mm	(0.0039 in.)
	Piston ring end gap	Top ring	0.20 ~ 0.33 mm (0.0079 ~ 0.0129 in.)	0.7 mm	(0.0275 in.)
		2nd ring	0.20 ~ 0.35 mm (0.0079 ~ 0.0137 in.)	0.7 mm	(0.0275 in.)
		Oil ring	0.20 ~ 0.70 mm (0.0079 ~ 0.0275 in.)	1.8 mm	(0.0708 in.)
	Crankshaft runout (middle)		_____	0.06 mm	(0.0023 in.)
Crank shaft	Crank pin diameter		41.982 ~ 42.000 mm (1.6529 ~ 1.6535 in.)	_____	_____
	Crank pin clearance in con. rod		0.030 ~ 0.050 mm (0.0012 ~ 0.0019 in.)	0.08 mm	(0.0031 in.)
	Connecting rod small end bore		16.968 ~ 16.979 mm (0.6680 ~ 0.6684 in.)	_____	_____
	Crank journal diameter		44.982 ~ 45.000 mm (1.7710 ~ 1.7716 in.)	_____	_____
	Bearing-to-journal clearance		0.020 ~ 0.040 mm (0.0008 ~ 0.0016 in.)	0.06 mm	(0.0023 in.)
	Crank pin out-of-round and taper		_____	0.01 mm	(0.0004 in.)



Item			Standard		Service Limit	
Crankshaft	Crank journal out-of-round and taper		_____		0.01 mm	(0.0004 in.)
	Flywheel runout		_____		0.2 mm	(0.0078 in.)
	Crankshaft thrust play		0.11 – 0.31 mm	(0.0044 ~ 0.0122 in.)	0.38 mm	(0.0149 in.)
	Connecting rod big end side clearance		0.10 ~ 0.20 mm	(0.0039 ~ 0.0078 in.)	0.35 mm	(0.0137 in.)
	Connecting rod	Twist	_____		0.10 mm	(0.0039 in.)
		Bow	_____		0.05 mm	(0.0020 in.)

## CLUTCH & TRANSMISSION

Item			Standard		Service Limit	
Clutch	Facing wear (Rivet head depth)		1.2 mm	(0.05 in.)	0.5 mm	(0.02 in.)
	Facing-input shaft serration backlash		_____		0.8 mm	(0.03 in.)
Transmission	Clearance between gears and rings	Low & high	1.0 ~ 1.4 mm	(0.039 ~ 0.055 in.)	0.5 mm	(0.019 in.)
		5th speed	1.2 ~ 1.6 mm	(0.047 ~ 0.063 in.)	0.5 mm	(0.019 in.)
	Key slot width of synchronizer ring		10.1 mm	(0.397 in.)	10.4 mm	(0.409 in.)
	Gear shift fork shaft spring free length		25.5 mm	(1.004 in.)	21.0 mm	(0.826 in.)
	Gear backlash		0.06 ~ 0.15 mm	(0.0024 ~ 0.0059 in.)	0.3 mm	(0.0118 in.)

## LUBRICATION

Item			Standard		Service Limit	
Lubrication	Radial clearance between outer rotor and case		_____		0.310 mm	(0.0122 in.)
	Oil pump side clearance (flatness)		_____		0.15 mm	(0.0059 in.)
	Oil relief valve spring	Free length	45 mm	(1.77 in.)	_____	
	Set pressure of oil pressure switch		0.2 ~ 0.4 kg/cm <sup>2</sup>	(2.84 ~ 5.68 psi)	_____	
	Engine oil pressure		3.0 ~ 4.2 kg/cm <sup>2</sup> (42.7 ~ 59.7 psi) at 3,000 r/min(rpm)		_____	

## COOLING SYSTEM

Item		Standard	Service Limit
Cooling system	Fan belt tension as deflection under 10 kg (22 lb) push applied to middle point between pulleys	6 ~ 9 mm (0.23 ~ 0.35 in.)	_____
	Thermostat start-to-open temperature	*82°C (179°F) or 88°C (190°F)	_____
	Thermostat full-open temperature	*95°C (203°F) or 100°C (212°F)	_____
	Valve lift	8 mm (0.31 in.)	_____

\* There are two types of thermostat depending on specifications.

## DIFFERENTIAL

Item		Standard	Service Limit
Differential	Bevel gear backlash	0.10 ~ 0.15 mm (0.004 ~ 0.006 in.)	_____
	Side gear thrust play	0.12 ~ 0.37 mm (0.005 ~ 0.014 in.)	_____
	Pinion bearing preload	1.8 ~ 3.4 kg (4.0 ~ 7.5 lbs.)	_____

## SUSPENSION

Item		Standard	Service Limit
Suspension	Front wheel bearing starting preload	1.0 ~ 3.0 kg (2.2 ~ 6.6 lbs.)	_____
	Rear wheel bearing thrust play	_____	0.8 mm (0.03 in.)
	Axial play in barfield joint	0 mm (No play)	1.5 mm (0.06 in.)
	Knackle arm starting torque (without oil seal)	1.0 ~ 1.8 kg (2.20 ~ 3.96 lbs.)	_____

## FUEL SYSTEM

Item	Standard	Limit
Engine idle speed	800 ± 50 r/min (rpm)	_____
Engine idle speed when turning A/C "ON"	1,000 ± 50 r/min (rpm)	_____

## STEERING SYSTEM

Item	Standard	Service Limit
Gear ratio	15.6 ~ 18.1	_____
Steering angle, inside	29°	_____
Steering angle, outside	26°	_____
Steering wheel play	10 ~ 30 mm (0.4 ~ 1.2 in.)	_____

## BRAKE

Item	Standard	Service Limit
Front brake disc thickness	10 mm (0.394 in.)	8.5 mm (0.334 in.)
Front brake disc deflection	_____	0.15 mm (0.006 in.)
Front brake pad thickness (lining + pad rim)	15.0 mm (0.590 in.)	6.0 mm (0.236 in.)
Rear brake lining thickness (lining + shoe rim)	7.0 mm (0.28 in.)	3.0 mm (0.12 in.)
Rear brake drum inside diameter	220 mm (8.66 in.)	222 mm (8.74 in.)
Pedal-to-wall clearance: When pedal is depressed at 30 kg (66 lb)	75 mm (2.95 in.) minimum	_____

## ELECTRICAL

Item		Standard	Service Limit
Ignition system	Ignition order	1 - 3 - 4 - 2	_____
	High tension cord resistance	10 ~ 22 kΩ/m 3.0 ~ 6.7 kΩ/ft	_____
	Ignition coil; Primary coil resistance (20°C, 68°F)	0.9 ~ 1.1 ohms	_____
	Ignition coil; Secondary coil resistance (20°C, 68°F)	10.2 ~ 13.8 kilohms	_____
	Spark plug gap	0.7 ~ 0.8 mm (0.027 ~ 0.031 in.)	_____

Prepared by  
**SUZUKI MOTOR CORPORATION**

Technical Department  
Automobile Service Division

1st Ed. May, 1989  
2nd Ed. May, 1991

Printed in Japan